

## 1. Basic Functions

- Year, month, day, hour, minute, temperature, humidity, level with screen display at a glance.
- Backlight, alarm clock, temperature (°C/°F) display, clock (12/24 hour) display, minimum/maximum temperature and humidity display.
- The main parts and components adopt imported with original packaging famous brand production to ensure the reliability of production.
- Sampling every 5 seconds with sensitivity and energy conservation
- IC and appearance patent with complete proprietary intellectual property right

## 2. Product Specifications

Specification: 106\*98\*22mm

Temperature Range: -58°F ~ +158°F (-50°C ~ +70°C)

Temperature Accuracy: ± 1.0°F (± 0.5°C) (59°F ~ 86°F)

Temperature Resolution: 0.1°F (0.1°C)

Humidity Range: 10%RH ~ 99%RH

Humidity Accuracy: ± 3%RH ~ ± 5%RH (40%RH ~ 80%RH)

Humidity Resolution: 1%RH


Battery: (1) AAA 1.5V battery required.

## 3. Operations

### 3.1 Keys

[MODE] Display time, alarm clock, 12/24 hour time display, year, month, day

[ADJ] Display calendar/adjust values.



 Lighten the backlight





[MEMORY] Display daily maximum/minimum temperature and humidity values from memory. Set new values into memory.

[C/F] Display switch °C/°F display.

3.2 Press [MODE] for 2 seconds in the original state, the minute of current time begins to flash; press [ADJ] to adjust the minute; press [MODE] and [ADJ] constantly to set the clock, 12/24 hour system, year, month and day.

## 4. The setting and cancelation of alarm clock function

4.1 Setting of alarm clock: Press [MODE] once in the mode of current clock, "Alarm" sign appears; press [ADJ] once, "Alarm" sign and  sign appear together; Press [MODE] for 2 seconds, the minute begins to flash; press the [ADJ] to set the minute of alarm clock; press [MODE] once, the hour begins to flash; press [ADJ] to set the hour of alarm clock; press [MODE] twice, the sign of  appears. Then return to the mode of current time. The setting is ok.

4.2 Cancelation of the alarm clock: In the current time mode with sign of  , press the [MODE] once, the sign of "Alarm" and the sign of  appear together; press [ADJ] once, the sign of  disappears; press [MODE] once, the sign of "Alarm" disappears; the  is cancelled, and the setting is ok.

5. Press [MEMORY] key once to view maximum/minimum temperature and humidity values for current date, Hold [MEMORY] key for 2 seconds to clear current values from memory.

## 6. Notes

6.1 Please keep the service environment clean for the corrosive gas and dust will decrease the measurement accuracy and reduce the service life of the device.

6.2 Please dispose discharged batteries responsibly and in accordance with law.