

Measure tolerance temperature: 0°C~50°C 32°F~122°F

Humidity:20%~98% Accuracy:±1°C 60%±5%

Method:

- 1、 Fix the until on a wall or place on desktop.
- 2、 Install the attached battery.
- 3、 Have a switch to select C/F in the backside of lowest humiture.
- 4、 Provide the measurement of the highest or lowest humiture.
- 5、 Pressing 'MODE' twice,will display 'MAX' or 'MIN'
- 6、 Pressing 'MAX' or 'MIN' once will display the previous the highest or lowest humiture.
- 7、 Clean up the highest and lowest humiture.
- 8、 Pressing 'RESET' once to Clean up the highest humiture.
When display 'MAX'
- 9、 Pressing 'RESET' once to Clean up the lowest humiture.
When display 'MIN'
- 10、 Resettest: When display 'MAX/MIN', 'MODE' once to exit, The unit will reset.
- 11、 If display blur please exchange battery .Use one 1.5volt AAA battery.