

TH308 clock, hygrometer manual

A Uses: This product is suitable for factories, warehouses, building air conditioning management, office, hotel, room, hospital, laboratory, seed breeding. Modern energy conservation is a good helper

B Use: Temperature: 0 °C ~ 50 °C (32 °F ~ 122 °F)

Accuracy: ± 1 °C (2 °F)

Resolution: 0.1 °C (0.1 °F)

Humidity: 10% ~ 99%

degree of error: ± 5% Resolution: 1%

Functional testing:

1 Press C / F button Celsius and Fahrenheit conversion

2 Press the MAX / MIN button to display the temperature and humidity for the most MAX MIN display shows temperature and humidity for the most

3. When the MAX or MIN, press the CLEAR button once to clear the memory of the previous value of 8 seconds automatic temperature and humidity sensors run out of re-

4 hours debugging: Press the ADJ key 12/24 hour conversion

Normal display press MODE key for 2 seconds minutes flashing, press the ADJ debugging minutes, and then press the MODE button the hour digits flash debug ADJ 1 hour in normal operation the MODE button

Alarm debug: Press the MODE key once to display the time is set, press MODE button for 2 seconds, minutes flash, press the ADJ debugging minutes, and then the MODE button once the hour digits flash. Press the ADJ key debugging hours, then the MODE button twice to return normal operation

** Font fuzzy, replace the battery.